



Tooling Holes for SIPAD Application

For square boards/arrays the holes can go in any or all corners. 2 is plenty however if possible all four corners adds flexibility to squeegee direction. Holes should be .125 non plated through

For rectangle boards/arrays the tooling holes should be on the longest edge.

